



SOUTHPAW®

Instruction Sheet VARIABLE AXIS SWING 4600

Store these instructions with the enclosed maintenance checklist in a safe place. You may also access them on our website.



Take time to familiarize yourself with the use and maintenance of this equipment before using. Please file this Instruction Sheet in an accessible location: the Instruction Sheet must be read and familiar to anyone who is using Southpaw Enterprises Equipment.

IMPORTANT: Please check equipment immediately for any damage that may have resulted during shipping. If any damage has occurred, please contact Southpaw Enterprises, Inc. immediately.

TOOLS NEEDED FOR ASSEMBLY: NONE

MATERIALS LIST: 1 - VARIABLE AXIS SWING 1 - SAFETY SNAP INSTRUCTION SHEET
1 - SAFETY SNAP 1 - MAINTENANCE CHECKLIST
1 - INSTRUCTION SHEET

IMPORTANT: KEEP ALL PARTS TOGETHER.

MINIMUM HEIGHT REQUIREMENT AND SPACE NEEDED: 8 Feet

- Equipment must be 6 feet from all walls and other obstacles.

HEIGHT ADJUSTOR OR SAFETY ROTATIONAL DEVICE NEEDED

A Southpaw Height Adjustor (5000) may be needed to adjust your equipment to the correct height for your client. With all Southpaw Enterprises, Inc. Suspended Equipment, a Southpaw Safety Rotational Device (2000) must be used to prevent damage to your equipment, except where specified otherwise.

All warranties are void if a Southpaw Rotational Device is not used or used with a rotational device not approved by Southpaw Enterprises, Inc.

HANGING STRAP

- Should the hanging strap come loose during shipping, or when it is removed for cleaning, attach it to the swing as follows: Wrap the webbing strap around the top of the aluminum frame two times, looping one end of the webbing under the other end **both times**. Then attach the safety snap to the webbing. At this point the webbing should tighten around the frame under load.

TO ADJUST THE ANGLE OF THE SWING

- **First, remove the client from the swing.** Next, loosen the positioning plate knobs on the sides of the swing until the teeth of the plates disengage. Rotate the angle of the seat to the desired position, and tighten knobs until the teeth of the positioning plates fully engage. **Do not loosen the knobs more than is necessary to adjust swing.**
- After adjusting the swing to the proper position, you may add additional stability to the seat by tying the cords to the outside loop of the frame.

IMPORTANT

- **NEVER ADJUST THE ANGLE OF THE SWING WHILE A CLIENT IS IN THE SWING. THIS COULD RESULT IN SERIOUS INJURY.**
- **Never use the swing without the provided safety restraint system.**
- **Never leave clients unattended in the Variable Axis Swing.**
- **Never use the swing without a Safety Rotational Device -- Failure to do so may result in catastrophic failure of the swing**
- Before placing a client in the swing, hang the swing and make sure the hanging strap is in place and secure. Failure to do this could result in serious injury.

MAINTENANCE CHECKLIST: All of the following wear points should be checked on a monthly basis and recorded on the checklist enclosed.

- Safety Snaps and all metal to metal connections, the Rotational Device and the top loop of the swing. See Safety Snap Instruction Sheet for maintenance checklist.
- A Southpaw Safety Rotational must be used at all times. See your Rotational Device Instruction Sheet for maintenance checklist.

Warning: Failure to properly install a Southpaw forged steel eyebolt (1/2" or 5/8") may result in serious injury or death. If you have any questions about the installation of the Southpaw forged steel eyebolt, please contact Southpaw Enterprises Customer Service at 1-800-228-1698.

Note: This product has a working load of 200 lbs.

- Check the top loop for wear, be sure the fabric is not worn or frayed. If found, discontinue use until repaired.
- Check for torn cover or ripped seams. If found, discontinue use until repaired.

WARNING: Check ceiling eye bolt for wear and movement. Use a Southpaw Safety Rotational Device to prevent abnormal wear. Floor mats of proper thickness should be positioned appropriately under and around.

NOTE

When replacing Safety Snaps or Rotational Devices due to normal wear use only Southpaw replacements.

We do not recommend the use of aluminum safety snaps or carabiniers although they may be lighter in weight or less expensive. Aluminum snaps will wear much faster than steel snaps. This wear may present a health hazard from handling with possible ingestion of aluminum particles.

MATTING PRECAUTIONS

ALWAYS USE APPROPRIATE MATTING.

STORAGE PROCEDURES

- Store out of direct sunlight
- Store where not accessible by clients without proper supervision.

CLEANING INSTRUCTIONS

- CHECK FOR CLIENT ALLERGIES FIRST.
- CHECK WITH YOUR INFECTIOUS DISEASE DEPARTMENT BEFORE USING THESE PROCEDURES.
- FABRIC MACHINE WASHABLE COLD WATER MILD DETERGENT
- AIR DRY (DO NOT TUMBLE DRY - COVER WILL MELT IN DRYER)
- CLEAN FRAME WITH A DAMP CLOTH USING SOAP AND WATER OR DISINFECTANT.

CAUTION

- ◆ **Check ceiling eye bolt for wear and movement. Use a Southpaw Safety Rotational Device to prevent abnormal wear.**
- ◆ **Floor mats of proper thickness should be positioned properly under and around all suspended equipment.**

Safety Precautions - The safety of your clients is dependent on the appropriate choice of activity to match, yet challenge their physical abilities. Use appropriate spotting / safety techniques. In addition, the layout of your activity area, proper installation and maintenance of your equipment is critical. Southpaw equipment is not intended for recreational or outdoor use. Under no condition should this equipment be used without proper supervision.

This sheet is for example only. It is not meant to, in any way, replace local, county, state, or Federal standards. Be aware - it is your responsibility to find all pertinent safety information that pertains to your facility.

If you have any questions or comments, please call or write
Southpaw Enterprises, Inc.

P.O. Box 1047, Dayton, Ohio 45401-1047

Toll Free - (800) 228-1698

Please visit us at southpaw.com

© 2024 Southpaw Enterprises, Inc.