



Instruction Sheet

Glider Bolster 1007 Mini

Store these instructions with the enclosed maintenance checklist in a safe place. You may also access them on our website.



Take time to familiarize yourself with the use and maintenance of this equipment before using. Please file this Instruction Sheet in an accessible location: the Instruction Sheet must be read and familiar to anyone who is using Southpaw Enterprises Equipment.

IMPORTANT: Please check equipment immediately for any damage that may have resulted during shipping. If any damage has occurred, please contact Southpaw Enterprises, Inc. immediately.

MATERIALS LIST

1007 Mini Glider Bolster

- 1 - Mini Glider Bolster 1007
- 2 - Safety Snaps 0100
- 1- Safety Snap instruction Sheet
- 1 - Instruction Sheet
- 1 - Maintenance Checklist

WORKING LOAD is 400 lbs.

SPACE REQUIREMENTS

- Minimum height must be 8 feet
- Clearance from walls and other obstacles must be at least 6 ft.

HANGING PROCEDURE

Note: Glider Bolster will hang from 2 or 4 suspension points. If 4 points are used, you will need 2 more safety snaps. Height Adjusters (5000) and Safety Rotational Devices (2000) are recommended but not included with Bolster. Be sure to use Southpaw Therapy Rope (0150) with Eye Splice with Southpaw Height Adjuster.


Attach your Glider to your ceiling eyebolts with the Safety Snaps provided.

Recommended suspension points for the Standard Glider Bolster, must be between 5-1/2 ft and 6-1/2 ft. apart as this is the most stable configuration. It *can* also be suspended from a single suspension point. Suspension points for the Mini Glider must be between 3-1/2 ft. and 5-1/2 ft. apart.

If you wish to suspend your Glider Bolster from 4 points you will need 2 additional Southpaw Safety Snaps. The second set of suspension points for the Glider Bolsters should be parallel to

The Glider Bolster is designed with different density foams on each side for the comfort of your clients. The top (blue) has one layer of soft foam and one layer of firm foam, and the bottom (green) has two layers of soft foam. Simply hang the bolster with the desired side facing up. The bolster is stable in both orientations.

Warning: Failure to properly install a Southpaw forged steel eyebolt (1/2" or 5/8") may result in serious injury or death. If you have any questions about the installation of the Southpaw forged steel eyebolt, please contact Southpaw Enterprises Customer Service at 1-800-228-1698.



Drawing shown with two Southpaw Height Adjustment Systems, not included

MAINTENANCE CHECKLIST

All of the following wear points should be checked on a monthly basis and recorded on the checklist enclosed.

- Lift eyebolt covers at the bottom of each rope and check eyebolts for wear.
- Check the metal lining on the rope where it contacts the eyebolt for wear.
- Look for metal dust or broken metal.
- Check all points where movement occurs for wear of any kind.
- Check Safety Snaps for wear. (See Safety Snap Instruction Sheet included).
- Check the cover for ripped or torn places.
- If rope splice locks are loose or missing, discontinue use until repaired.
- If ropes are fraying, item should be taken out of service. Call Southpaw for rope repair.

STORAGE PROCEDURES

- Store out of direct sunlight.
- Store where not accessible by clients without proper supervision.

CLEANING INSTRUCTIONS

Check with your infectious disease department before using these procedures.

- Check for client allergies first.
- Bolster may be cleaned with a damp cloth using soap and water or appropriate disinfectant.
- Lines may be cleaned with a damp cloth.
- Make sure unit is dry before using.

CAUTION

- ◆ **Check ceiling eyebolt for wear and movement. Use a Southpaw Safety Rotational Device to prevent abnormal wear.**
- ◆ **Floor mats of proper thickness should be positioned properly under and around all suspended equipment.**

Safety Precautions - The safety of your clients is dependent on the appropriate choice of activity to match, yet challenge their physical abilities. Use appropriate spotting / safety techniques. In addition, the layout of your activity area, proper installation and maintenance of your equipment is critical. Southpaw equipment is not intended for recreational or outdoor use. Under no condition should this equipment be used without proper supervision.

This sheet is for example only. It is not meant to, in any way, replace local, county, state, or Federal standards. Be aware - it is your responsibility to find all pertinent safety information that pertains to your facility.

If you have any questions or comments, please call or write

Southpaw Enterprises, Inc.

P.O. Box 1047, Dayton, Ohio 45401-1047

Toll Free - (800) 228-1698

Please visit us at southpaw.com

© 2026 Southpaw Enterprises, Inc.