



## Instruction Sheet

Store these instructions along with the enclosed maintenance checklist in a safe place. You may also access them on our website.

## *Advantage Line* Standard Bolster 120050



Take time to familiarize yourself with the use and maintenance of this equipment before using. Please file this Instruction Sheet in an accessible location: the Instruction Sheet must be read and familiar to anyone who is using Southpaw Enterprises Equipment. If this Instruction Sheet is misplaced, please call or write for a replacement. (See address below).

**IMPORTANT: Please check equipment immediately for any damage that may have resulted during shipping. If any damage has occurred, please contact Southpaw Enterprises, Inc. immediately.**

**Warning:** Failure to properly install a forged steel eyebolt (1/2" or 5/8") may result in serious injury or death. If you have any questions about the installation of the forged steel eyebolt, please contact Southpaw Enterprises Customer Service at 1-800-228-1698.

### MATERIALS LIST:

- 1 - Bolster Swing
- 1 - Safety Snap
- 1 - Instruction Sheet
- 1 - Maintenance Checklist
- 1 - Safety Snap Instruction Sheet

### MINIMUM HEIGHT REQUIREMENT AND SPACE NEEDED:

- Can be used with an 8 foot ceiling
- Caution must be taken to keep a clear distance of 6 feet from walls and other obstacles.

### HEIGHT ADJUSTER AND ROTATIONAL DEVICE NEEDED:

- For ease of adjustment, a Southpaw Height Adjuster (Part # 5000) is recommended.
- A Southpaw Safety Rotational Device (Part # 2000) must be used to prevent damage to your equipment.

**WORKING LOAD:** 300 POUNDS

### HANGING PROCEDURE:

To hang your bolster attach the safety snap on the top of the bolster to a rotational device, then to your suspension point. Your Southpaw Bolster is now ready to use.

### MAINTENANCE CHECKLIST:

All of the following wear points should be checked on a monthly basis and recorded on the checklist enclosed

- Check ropes for fraying (be sure to check end of rope under black boot).
- Check all Safety Snaps for wear. Refer to the Safety Snap Instruction Sheet for detailed maintenance checklist.
- Check ropes for loose or missing metal rope clips. If found discontinue use.
- Check bar for cracks or splinters. If cracks are found discontinue use. If splinters are found sand until smooth and refinish with clear lacquer.

### STORAGE PROCEDURES:

- Store out of Direct Sunlight.
- Store where not accessible by clients without proper supervision.

### CLEANING INSTRUCTIONS:

- Check for client allergies first.
- Check with your infectious disease department before using these procedures.
- Wash using a damp cloth with mild soap and water. Dry before using.
- Do not use abrasive cleaners.

## **CAUTION**

- ◆ **Check ceiling eye bolt for wear and movement. Use a Southpaw Safety Rotational Device to prevent abnormal wear.**
- ◆ **Floor mats of proper thickness should be positioned properly under and around all suspended equipment.**

**Safety Precautions** - The safety of your clients is dependent on the appropriate choice of activity to match, yet challenge their physical abilities. Use appropriate spotting / safety techniques. In addition, the layout of your activity area, proper installation and maintenance of your equipment is critical. Southpaw equipment is not intended for recreational or outdoor use. Under no condition should this equipment be used without proper supervision.

**This sheet is for example only.** It is not meant to, in any way, replace local, county, state, or Federal standards. Be aware - it is your responsibility to find all pertinent safety information that pertains to your facility.

If you have any questions or comments, please call or write

Southpaw Enterprises, Inc.

P.O. Box 1047, Dayton, Ohio 45401 -1047

Toll Free - (800) 228-1698

Please visit us @ [www.southpaw.com](http://www.southpaw.com)

© 2019 Southpaw Enterprises, Inc.