



Instruction Sheet

Flying Purple People Eater 120090

Flying Purple People Eater Cover Only 120095

Store these instructions along with the enclosed maintenance checklist in a safe place. You may also access them on our website.



Take time to familiarize yourself with the use and maintenance of this equipment before using. Please file this Instruction Sheet in an accessible location: The Instruction Sheet must be read and familiar to anyone who is using Southpaw Enterprises Equipment.

IMPORTANT: Please check equipment immediately for any damage that may have resulted during shipping. If any damage has occurred, please contact Southpaw Enterprises, Inc. immediately.

Warning: Failure to properly install a forged steel eyebolt (1/2" or 5/8") may result in serious injury or death. If you have any questions about the installation of the forged steel

MATERIALS LIST 120090:

- 1 - Flying Purple People Eater
- 1 - Stabilizer Board
- 1 - Safety Snap
- 1 - Instruction Sheet
- 1 - Safety Snap Instruction Sheet
- 1 - Maintenance Checklist

MATERIALS LIST 120095

- 1 - Flying Purple People Eater Cover
- 1 - Instruction Sheet

WORKING LOAD: 200 lbs.

HANGING INSTRUCTIONS:

- Attach the safety snap to the loops on top of the Purple People Eater, then attach the safety snap to your suspension point.
- The Southpaw Height Adjuster (# 5000) will allow you to adjust the height of your equipment to best suit your needs.

The Flying Purple People Eater may be filled with different kinds of media such as balls or other things deemed appropriate.

MATTING PRECAUTIONS:

Always use appropriate matting under and around suspended equipment.

MAINTENANCE CHECKLIST:

All of the following wear points should be checked on a monthly basis and recorded on the checklist enclosed.

- Check for ripped seams or loose stitches. If ripped seams or loose stitches are found, discontinue use until repaired.
- Check wood parts for cracks and splinters. If cracks are found, discontinue use until repaired. Sand splinters until smooth.

STORAGE PROCEDURE:

- Store where not accessible without proper supervision.
- Store out of direct sunlight.

CLEANING INSTRUCTIONS:

Check with your infectious disease department before using these procedures.

- Check for client allergies first.
- After removing all wood pieces, fabric may be machine washed using cold water and mild detergent. *See back side to remove wood from fabric.*
- Tumble dry, low heat.

TO REMOVE THE COVER:

- Open the door of the swing and turn the top portion inside out.
- Locate the opening in the purple fabric located at the junction of the purple and the black fabric.
- Remove the screw and washers holding the two ends of the circular piece of wood together with a 7/32" hex key wrench.
- Slide the circular piece of wood out of the fabric.

TO REPLACE THE COVER:

- Open the door of the swing and turn the top portion inside out.
- Locate the opening in the purple fabric located at the junction of the purple and the black fabric.
- Slide one end of the circular wood piece into the opening in the purple fabric located at the junction of the purple and the black fabric.
- NOTE: one end of the wood circle has a threaded insert in it. The insert has a "washer" on one side (fig. 1). The screw goes into the opposite side from the washer.
- When putting the wood circle into the fabric, be sure that the washer is facing the black fabric. Slide the fabric around the wood circle until both ends are at the opening (fig. 2).
- Put the split lock washer, then the flat washer on the screw. Put the screw into the hole without the threaded insert. Overlap the ends of the wood until the holes are aligned and start the screw into the threaded insert and tighten securely (fig. 3).
- Turn the fabric right side out and hang.

Figure 1




Figure 2



Figure 3



CAUTION

- ◆ **Check ceiling eye bolt for wear and movement. Use a Southpaw Safety Rotational Device to prevent abnormal wear.**
- ◆ **Floor mats of proper thickness should be positioned properly under and around all suspended equipment.**

Safety Precautions - The safety of your clients is dependent on the appropriate choice of activity to match, yet challenge their physical abilities. Use appropriate spotting / safety techniques. In addition, the layout of your activity area, proper installation and maintenance of your equipment is critical. Southpaw equipment is not intended for recreational or outdoor use. Under no condition should this equipment be used without proper supervision.

This sheet is for example only. It is not meant to, in any way, replace local, county, state, or Federal standards. Be aware - it is your responsibility to find all pertinent safety information that pertains to your facility.

If you have any questions or comments, please call or write

Southpaw Enterprises, Inc.

P.O. Box 1047, Dayton, Ohio 45401 -1047

Toll Free - (800) 228-1698

Please visit us @ www.southpaw.com

© 2019Southpaw Enterprises, Inc.