

Store these instructions along with the enclosed maintenance checklist in a safe place. You may also access them on our website.

Instruction Sheet Barrel Swing Large 120145

Take time to familiarize yourself with the use and maintenance of this equipment before using. Please file this Instruction Sheet in an accessible location. The Instruction Sheet must be read and familiar to anyone who is using Southpaw Enterprises Equipment.

IMPORTANT: Please check equipment immediately for any damage that may have resulted during shipping. If any damage has occurred, please contact Southpaw Enterprises, Inc. immediately.

MATERIALS LIST:

- 1 Barrel Swing
- 3 Safety Snaps
- 1 Trapeze Bar
- 2 Ropes 2 - Spreader Bars

STOP

- 1 Instruction Sheet
- 1 Maintenance Checklist
 - 1 Safety Snap Instruction Sheet
- 4 Lynch Pin Clips

TO SUSPEND THE BARREL SWING:

- Refer to figure 1 on the right to help with assembly. •
- Attach the trapeze bar to your suspension point using one of the safety snaps provided.
- Starting on one end of the barrel, pass one end of one of the vinyl covered ropes through the three web loops on one end of the barrel. Bring the ends of the rope together and put a safety snap through the loop on each end of the rope. Repeat on opposite end of the barrel.
- Attach the safety snaps on the ropes to the web loops at each end of the trapeze bar.
- Remove the lynch pin clips from the ends of the spreader bars by pivoting the ring up over the end of the bar and then pull the clip out of the hole. Insert the spreader bars between the ropes above the vinyl tube covering the rope. Insert a clip through the

hole in the end of the spreader bar and pivot the lock ring into position. Make sure that the rope is captured between the bottom of the slot and the lynch pin. Repeat on each end of both spreader bars. Pull the spreader down until they rest on top of the tube covering the rope. Assembly is complete.

WORKING LOAD: 350 lbs.

Replacement covers for the Barrel Swings (#120141 Small) and (#120146 Large) are available from Southpaw.

A Southpaw Safety Rotational Device (#2000) must be used with any rotational movement to prevent damage to the equipment.

MAINTENANCE CHECKLIST:

All of the following wear points must be checked on a monthly basis and recorded on the checklist enclosed.

- Check all Safety Snaps for wear. Refer to the Safety Snap Instruction Sheet for detailed maintenance checklist.
- Check ropes for fraying. If fraying is found, discontinue use until repaired. •
- Check loops for fraying or split threads discontinue use if found.
- Check ropes for loose or missing splice locks.* If loose or missing splice locks are found, discontinue use until repaired.
- Check bar for cracks or splinters. If cracks are found discontinue use. If splinters are found sand smooth and refin-• ish with clear lacquer
- Check seams for loose or missing stitches. If loose or missing stitches are found, discontinue use until repaired.
- * A splice lock is the metal clip near the end of the ropes.

Warning: Failure to properly install a forged steel eyebolt (1/2" or 5/8") may result in serious injury or death. If you have any questions about the installation of the forged steel eyebolt, please contact Southpaw Enterprises

Figure 1

STORAGE PROCEDURES

- Store out of direct sunlight
- Store where not accessible by clients without proper supervision

CLEANING INSTRUCTIONS

- Check for client allergies first.
- Check with your infectious disease department before using these procedures.
- Wash using a damp cloth with mild soap and water or disinfectant.
- Dry before using.

CAUTION

- Check ceiling eye bolt for wear and movement. Use a Southpaw Safety Rotational Device to prevent abnormal wear.
- Floor mats of proper thickness should be positioned properly under and around all suspended equipment.

Safety Precautions - The safety of your clients is dependent on the appropriate choice of activity to match, yet challenge their physical abilities. Use appropriate spotting / safety techniques. In addition, the layout of your activity area, proper installation and maintenance of your equipment is critical. Southpaw equipment is not intended for recreational or outdoor use. Under no condition should this equipment be used without proper supervision.

This sheet is for example only. It is not meant to, in any way, replace local, county, state, or Federal standards. Be aware - it is your responsibility to find all pertinent safety information that pertains to your facility.

If you have any questions or comments, please call or write Southpaw Enterprises, Inc. P.O. Box 1047, Dayton, Ohio 45401 -1047 Toll Free - (800) 228-1698 Please visit us at www.southpaw.com © 2019 Southpaw Enterprises, Inc.