



southpaw enterprises, inc.[®]

Store these instructions in a safe place or with the enclosed maintenance checklist

Instruction Sheet

U-Boat Swing 126022



Take time to familiarize yourself with the use and maintenance of this equipment before using. Please file this Instruction Sheet in an accessible location: the Instruction Sheet must be read and familiar to anyone who is using Southpaw Enterprises Equipment.

Warning: Failure to properly install a forged steel eyebolt (1/2" or 5/8") may result in serious injury or death. If you have any questions about the installation of the forged steel eyebolt, please contact Southpaw Enterprises Customer Service at 1-800-228-1698.

IMPORTANT: Please check equipment immediately for any damage that may have resulted during shipping. If any damage has occurred, please contact Southpaw Enterprises, Inc. immediately.

MATERIALS LIST

- | | |
|---|-----------------------------------|
| 1 - U-Boat Swing | 1 - Instruction Sheet |
| 1 - Carpet with Hook Pads on under side | 1 - Safety Snap Instruction Sheet |
| 2 - Safety Snaps | 1 - Maintenance Checklist |

IMPORTANT: KEEP ALL PARTS TOGETHER.

MINIMUM HEIGHT REQUIREMENT AND SPACE NEEDED

Height Requirement: 8 feet.

Space needed: Assure a clear distance of 6 feet from walls and other obstacles.

HEIGHT ADJUSTER OR SAFETY ROTATIONAL DEVICE NEEDED

- Southpaw Height adjuster (5000) is recommended but not included for ease of adjustment to proper height.
- Southpaw Safety Rotational Device (2000) must be used if suspended from a single point. Be sure to use Southpaw Therapy Rope (150) and Eye Splice (151) with Southpaw Height Adjuster (5000).

WORKING LOAD: 250 lbs.

SUSPENSION PROCEDURES

- Attach your U-Boat swing to your support eye bolts with the Safety Snaps provided.
- To suspend your U-Boat swing from two points: Suspension points must be between 3-1/2 feet and 4-1/2 feet apart.
- To suspend your U-Boat swing from one point: A Southpaw Safety Rotational Device must be used to prevent damage by rotation.

MAINTENANCE CHECKLIST

All of the following wear points should be checked on a monthly basis and recorded on the checklist enclosed.

- Check Safety Snaps for wear. See the enclosed Safety Snap Instruction Sheet for inspection guidelines.
- Check the ropes for loose or missing splice locks.

NOTE: A splice lock is the metal rope staple near both ends of the rope.

- Check the ropes for wear at the top end where it rubs against the Safety Snaps and at the bottom end where it goes through the holes in the board. If there is excessive wear, discontinue use and call Southpaw to replace ropes.
- Check all wooden parts for chips or splinters. If found, discontinue use until repaired. To repair, sand smooth and refinish with polyurethane.
- Check hook and loop fasteners on both the carpet and the board to make sure they are securely attached.

STORAGE PROCEDURES

- Store out of direct sunlight.
- Store away from all chemicals and household cleaners.
- Store where not accessible by clients without proper supervision.

CLEANING INSTRUCTIONS

- Check with your infectious disease department before using these procedures.
- Check for client allergies first.
- Wipe vinyl with a damp cloth using soap and water or disinfectant. Dry before using.
- Vacuum carpet often, and clean with foam carpet cleaner. Dry before using.
- Carpet is not machine washable.
- Do not immerse in water.

CAUTION

- ◆ **Check ceiling eye bolt for wear and movement. Use a Southpaw Safety Rotational Device to prevent abnormal wear.**
- ◆ **Floor mats of proper thickness should be positioned properly under and around all suspended equipment.**

Safety Precautions - The safety of your clients is dependent on the appropriate choice of activity to match, yet challenge their physical abilities. Use appropriate spotting / safety techniques. In addition, the layout of your activity area, proper installation and maintenance of your equipment is critical. Southpaw equipment is not intended for recreational or outdoor use. Under no condition should this equipment be used without proper supervision.

This sheet is for example only. It is not meant to, in any way, replace local, county, state, or Federal standards. Be aware - it is your responsibility to find all pertinent safety information that pertains to your facility.



If you have any questions or comments, please call or write
 Southpaw Enterprises, Inc.
 P.O. Box 1047, Dayton, Ohio 45401 -1047
 Toll Free - (800) 228-1698
 Come see us on the World Wide Web at <http://southpawenterprises.com>