



Store these instructions in a safe place or you may access them on our website.

# Instruction Sheet

## Play Loft White LED Rope Light 150225



Take time to familiarize yourself with the use and maintenance of this equipment before using. Please file this Instruction Sheet in an accessible location. The Instruction Sheet must be read and familiar to anyone who is using Southpaw Enterprises Equipment.

**IMPORTANT: Please check equipment immediately for any damage that may have resulted during shipping. If any damage has occurred, please contact Southpaw Enterprises, Inc. immediately.**

### MATERIALS LIST:

1 - 9 foot Rope Light w/cord	1 - Instruction Sheet
10 - Mounting Clips	1 - Maintenance Checklist
10 - # 4 x 1/2" Phillips Head Screws	

The Rope light can be installed under the deck of the Play Loft or hand held to create a serene, calming space.

Works well in conjunction with the Hideaway Flaps.

**CAUTION: Do not use without constant adult supervision.**

### INSTALLATION IN LOFT:

**TOOLS NEEDED** - Drill, 3/32" drill bit, Phillips head screwdriver.

- Arrange rope clips on the underneath side of the floor of the Loft to hold the Rope Light in the position you want. The rope clips should be spaced approximately 1 foot apart.
- Wrap a piece of tape around the 3/32" drill bit leaving 1/2" of the tip exposed. This will give you a guide so that you don't drill through the floor of the Loft. Drill a pilot hole for the screw 1/2" deep at the point where you want the rope clip.
- Insert a screw through the hole closest to the clip. Start the screw into the pilot hole and tighten the screw securely. Use caution not to over tighten the screw. This could cause the clip to break.
- After installing all of the clips, insert the Rope Light into the clips to hold it in place.
- You will most likely need an extension cord to connect the light cord to a 120 volt wall outlet. Use only a UL approved extension cord.

### MAINTENANCE CHECKLIST:

All of the following wear points should be checked on a monthly basis and recorded on the checklist enclosed.

- Check that the screw on connection between the cord and the rope light is tight.
- Check the end cap on the end of the rope light is secure.
- Check the light and extension cord is not frayed exposing any wires.

### CLEANING INSTRUCTIONS:

- Check with your infectious disease department before using these procedures.
- Check for client allergies first.
- **UNPLUG FROM WALL OUTLET BEFORE ATTEMPTING TO CLEAN.**
- Wipe with a damp cloth using mild soap and water of disinfectant.
- Dry before using.

**Safety Precautions** - The safety of your clients is dependent on the appropriate choice of activity to match, yet challenge their physical abilities. Use appropriate spotting / safety techniques. In addition, the layout of your activity area, proper installation and maintenance of your equipment is critical. Southpaw equipment is not intended for recreational or outdoor use. Under no condition should this equipment be used without proper supervision.

**This sheet is for example only.** It is not meant to, in any way, replace local, county, state, or Federal standards. Be aware - it is your responsibility to find all pertinent safety information that pertains to your facility.

If you have any questions or comments, please call or write  
Southpaw Enterprises, Inc.  
P.O. Box 1047, Dayton, Ohio 45401 -1047  
Toll Free - (800) 228-1698  
Visit us at southpaw.com

© 2024 Southpaw Enterprises, Inc.