



Store these instructions along with the enclosed maintenance checklist in a safe place. You may also access them on our website.

Instruction Sheet: Adult Sensory Rocker 154050



Take time to familiarize yourself with the use and maintenance of this equipment before using. Please file this Instruction Sheet in an accessible location. The Instruction Sheet must be read and familiar to anyone who is using Southpaw Enterprises Equipment.

IMPORTANT: Please check equipment immediately for any damage that may have resulted during shipping. If any damage has occurred, please contact Southpaw Enterprises, Inc. immediately.

MATERIALS LIST:

1 - Rocker

INSTALLATION INSTRUCTIONS :

The Rocker comes delivered completely assembled.

MAINTENANCE:

Recommended cleaning solution is 50/50 solution of Hydrogen Peroxide to water including a teaspoon of dish detergent per gallon. A soft cotton cloth should also be used.

Care should be taken to remove all sharp objects from pockets, as well as all metal braces or braces containing metal snaps or connectors, prior to sitting on the Rocker.

Safety Precautions - The safety of your clients is dependent on the appropriate choice of activity to match, yet challenge their physical abilities. Use appropriate spotting / safety techniques. In addition, the layout of your activity area, proper installation and maintenance of your equipment is critical. Southpaw equipment is not intended for recreational or outdoor use. Under no condition should this equipment be used without proper supervision.

This sheet is for example only. It is not meant to, in any way, replace local, county, state, or Federal standards. Be aware - it is your responsibility to find all pertinent safety information that pertains to your facility.

If you have any questions or comments, please call or write

Southpaw Enterprises, Inc.

P.O. Box 1047, Dayton, Ohio 45401-1047

Toll Free - (800) 228-1698

Please visit us at southpaw.com

© 2025 Southpaw Enterprises, Inc.