


This expansion fixing and screw to be inserted below the plate as shown - this fixing only




THREE EXPANSION FIXINGS BETWEEN
PLATE AND BASE, ONE BELOW PLATE
FITTING THE MOUNTING PLATE

STEP 1
Remove the rubber foot from the
bottom of the Light Source

STEP 2
Push fit three of the expansion fittings
into the the holes vacated by the foot
as shown - DO NOT fit an expansion
fitting into the foot hole at the rear
below the push buttons

STEP 3
Place the mounting plate on the base as
shown and push the remaining expansion
fitting through the plate into the hole that
does not have one fitted. Fit all four screws
and tighten. Do not over tighten



**WARNING - FAILURE TO FOLLOW THESE INSTRUCTIONS MAY
RESULT IN DAMAGE TO THE LED LIGHT SOURCE**