



Instruction Sheet

Vibro Sensory Corner #303110

Store these instructions with the enclosed maintenance checklist in a safe place. You may also access them on our website.



Take time to familiarize yourself with the use and maintenance of this equipment before using. Please file this Instruction Sheet in an accessible location. The Instruction Sheet must be read and familiar to anyone who is using Southpaw Enterprises Equipment. If this Instruction Sheet is misplaced, please call or write for a replacement. (See address below).

IMPORTANT: Please check equipment immediately for any damage that may have resulted during shipping. If any damage has occurred, please contact Southpaw Enterprises, Inc. immediately.

MATERIALS LIST

-Wooden Vibro Frame	-Wall Pads (2)
-Floor Pad	-24' Speaker Wire
-Hanging Strip (2)	-6" Tall Bolsters (2)
	-2" Velcro

TOOLS NEEDED

- Cordless Drill
- 3/16" Drill bit
- #2 Phillips Bit
- Southpaw Radio Rover or 100W max stereo

INSTRUCTIONS FOR ASSEMBLY

Place the wooden floor into a corner of the room. Mark a line on both walls 60" above top of the wooden floor. Position the Hanging Strips so the top of the Strip is on your mark. Mark the holes for anchor placement. Use a 3/16" drill bit for the anchor holes. After placing anchors, screw the Hanging Strips to the walls. The bottom of the wall pads should rest on top of the wooden floor.

Place the Floor Pad on top of the Wooden Floor. Position the Bolsters on the floor next to the Wooden Floor. Use the 2" Velcro to secure the Bolsters to the Wooden Floor.

To connect the Sensory Corner to a Southpaw Radio Rover, Mini Rover or Wall Stereo, take the 24" of speaker wire (included) and plug the RCA jack into the RCA connection on the Sensory Corner and the RCA connection on the Radio Rover. Use with any other stereo equipment will void the warranty.

Safety Precautions - The safety of your clients is dependent on the appropriate choice of activity to match, yet challenge their physical abilities. Use appropriate spotting / safety techniques. In addition, the layout of your activity area, proper installation and maintenance of your equipment is critical. Southpaw equipment is not intended for recreational or outdoor use. Under no condition should this equipment be used without proper supervision.

This sheet is for example only. It is not meant to, in any way, replace local, county, state, or Federal standards. Be aware - it is your responsibility to find all pertinent safety information that pertains to your facility.

If you have any questions or comments, please call or write

Southpaw Enterprises, Inc.

P.O. Box 1047, Dayton, Ohio 45401-1047

Toll Free - (800) 228-1698

Please visit us at southpaw.com

© 2026 Southpaw Enterprises, Inc.