



southpaw enterprises, inc.®

Store these instructions with the enclosed maintenance checklist in a safe place. You may also access them on our website.

Instruction Sheet

Air Walker 0145



Take time to familiarize yourself with the use and maintenance of this equipment before using. Please file this Instruction Sheet in an accessible location: the Instruction Sheet must be read and familiar to anyone who is using Southpaw Enterprises Equipment.

IMPORTANT: Please check equipment immediately for any damage that may have resulted during shipping. If any damage has occurred, please contact Southpaw Enterprises, Inc. immediately.

MATERIALS LIST:

- 1 - Air Walker
- 1 - Built-in Safety Rotational Device
- 1 - Instruction Sheet
- 1 - Maintenance Checklist

Warning: Failure to properly install a forged steel eyebolt (1/2" or 5/8") may result in serious injury or death. If you have any questions about the installation of the forged steel eyebolt, please contact Southpaw Enterprises Customer Service at 1-800-228-1698.

MINIMUM HEIGHT REQUIREMENT AND SPACE NEEDED:

- Height - 8 feet.
- Equipment must be 6 feet from walls or other obstacles.

HEIGHT ADJUSTER OR SAFETY ROTATIONAL NEEDED:

- A Southpaw Height Adjuster (#5000) may be needed to adjust the equipment to the correct height for your client.

MAINTENANCE CHECKLIST:

All of the following wear points should be checked on a monthly basis and recorded on the checklist enclosed.

- Check the top loop for fraying or excessive wear. If found, discontinue use until repaired.
- Check for loose stitching or ripped seams. If found, discontinue use until repaired.
- Check Safety Snaps for wear. See your Safety Snap Instruction Sheet for inspection guidelines.

WARNING: Check your ceiling eye bolt for wear and movement. Use built-in safety rotational device to prevent abnormal wear.

We do not recommend the use of aluminum safety snaps or carabiners although they may be lighter in weight and less expensive. Aluminum snaps will wear much faster than steel snaps. This wear may present a health hazard from handling with possible ingestion of aluminum particles. When replacing safety snaps due to normal wear use only Southpaw replacement parts.

MATTING PRECAUTIONS: Always use appropriate matting.

STORAGE PROCEDURES:

- Store out of direct sunlight.
- Store where not accessible by clients without proper supervision.
- Return product to its original storage container when not in use.

CLEANING INSTRUCTIONS:

- Check with your infectious disease department before using these procedures.
- Check for client allergies first.
- Dry clean - or - hand washable with mild detergent. Make sure to keep the top joining area dry.
- Air dry before using.

CAUTION

- ◆ **Check ceiling eye bolt for wear and movement. Use a Southpaw Safety Rotational Device to prevent abnormal wear.**
- ◆ **Floor mats of proper thickness should be positioned properly under and around all suspended equipment.**

Safety Precautions - The safety of your clients is dependent on the appropriate choice of activity to match, yet challenge their physical abilities. Use appropriate spotting / safety techniques. In addition, the layout of your activity area, proper installation and maintenance of your equipment is critical. Southpaw equipment is not intended for recreational or outdoor use. Under no condition should this equipment be used without proper supervision.

This sheet is for example only. It is not meant to, in any way, replace local, county, state, or Federal standards. Be aware - it is your responsibility to find all pertinent safety information that pertains to your facility.



If you have any questions or comments, please call or write
Southpaw Enterprises, Inc.
P.O. Box 1047, Dayton, Ohio 45401 -1047
Toll Free - (800) 228-1698
Come see us on the World Wide Web at <http://southpawenterprises.com>