



# southpaw enterprises, inc.®

## Instruction Sheet Dual Swing 1600

Store these instructions in a safe place with the enclosed maintenance checklist. You may also access it on our website.



Take time to familiarize yourself with the use and maintenance of this equipment before using. Please file this Instruction Sheet in an accessible location: the Instruction Sheet must be read and familiar to anyone who is using Southpaw Enterprises Equipment.

**IMPORTANT: Please check equipment immediately for any damage that may have resulted during shipping. If any damage has occurred, please contact Southpaw Enterprises, Inc. immediately.**

Warning: Failure to properly install a forged steel eyebolt (1/2" or 5/8") may result in serious injury or death. If you have any questions about the installation of the forged steel eyebolt, please contact Southpaw Enterprises Customer Service at 1-800-228-1698.

### MATERIALS LIST:

4 - Lines with Leg Lifts	1 - Instruction Sheet for Safety Snaps
2 - Safety Snaps	1 - Maintenance Checklist
1 - Instruction Sheet	

**Minimum height requirement and space needed:** 8 ft.

Be sure to keep a clear distance of 6 ft. from walls and other obstacles.

**Working Load:** 400 lbs

### Hanging Instructions:

To hang your Southpaw Dual Swing use the safety snap which comes attached to your swing and attach it to your suspension system. Dual Swing can be used with two or four loop configuration with one or two clients depending on appropriate nature.

### MAINTENANCE CHECKLIST:

All of the following wear points should be checked on a monthly basis and recorded on the checklist enclosed.

Contact Southpaw for replacement or repair of worn or frayed parts immediately.

Check top of loops for loose or missing stitches. Discontinue use if loose or missing stitches are found.

Check for sharp or hard corners on cut edge of web loops. If found, they may be softened with a file using care not to cut stitches.

Check Safety Snaps for wear. See enclosed Instruction Sheet for Safety Snaps.

Check for loose or missing splice locks\* on ropes. Discontinue use if rope loops are frayed, or loose or missing splice locks are found.

\* Splice locks are the metal rope staples near both ends of the white rope.

### STORAGE PROCEDURES:

Store where not accessible by clients without proper supervision. Store out of direct sunlight.

### CLEANING INSTRUCTIONS:

Ropes and loops may be hand washed with mild detergent and cold water.

Do not bleach.

Hang to dry.

Dry before using.

## CAUTION

- ◆ Check ceiling eye bolt for wear and movement. Use a Southpaw Safety Rotational Device to prevent abnormal wear.
- ◆ Floor mats of proper thickness should be positioned properly under and around all suspended equipment.

**Safety Precautions** - The safety of your clients is dependent on the appropriate choice of activity to match, yet challenge their physical abilities. Use appropriate spotting / safety techniques. In addition, the layout of your activity area, proper installation and maintenance of your equipment is critical. Southpaw equipment is not intended for recreational or outdoor use. Under no condition should this equipment be used without proper supervision.

**This sheet is for example only.** It is not meant to, in any way, replace local, county, state, or Federal standards. Be aware - it is your responsibility to find all pertinent safety information that pertains to your facility.



## Southpaw Enterprises Inc.®

If you have any questions or comments, please call or write

Southpaw Enterprises, Inc.

P.O. Box 1047, Dayton, Ohio 45401 -1047

Toll Free - (800) 228-1698

Come see us on the World Wide Web at <http://southpawenterprises.com>