



**southpaw enterprises, inc.®**

Store these instructions along with the enclosed maintenance checklist in a safe place. You may also access them on our website.

## **Instruction Sheet - Bubble Tube with Ping Pong Insert and Padded Platform #303104**



Take time to familiarize yourself with the use and maintenance of this equipment before using. Please file this Instruction Sheet in an accessible location. The Instruction Sheet must be read and familiar to anyone who is using Southpaw Enterprises Equipment.

**IMPORTANT: Please check equipment immediately for any damage that may have resulted during shipping. If any damage has occurred, please contact Southpaw Enterprises, Inc. immediately.**

### **MATERIALS LIST**

- |                            |                           |                                     |
|----------------------------|---------------------------|-------------------------------------|
| -Wooden Platform           | -Pinch Valve              | -Instruction Sheet                  |
| -White vinyl-covered Pad   | -LED Remote Control       | -Security Bracket Instruction Sheet |
| -6" Acrylic Tube           | -Funnel                   | -Maintenance Checklist              |
| -2" Acrylic Tube           | -Allen Wrench             |                                     |
| -6 Colored Ping Pong Balls | -Bubble Column Drain Hose |                                     |
| -Allen Wrench              | -Algae Preventer Solution |                                     |
| -4 Screws                  | -Security Bracket         |                                     |

### **A. INSTRUCTIONS FOR ASSEMBLY**

Remove small lid on top of the wooden Platform. Place Bubble Column on top of the wooden slats positioning the holes in the acrylic base over the pre-drilled holes on the slats and the air hose pointed toward the front of the Platform (i.e. opposite the side where the electrical plugs are located). Tighten screws with Allen Wrench. Connect hose fittings from the base of the Bubble Column to the fitting on the underside of platform. Push together until you hear a "snap."

### **USE DISTILLED WATER ONLY TO FILL BUBBLE COLUMN**

Column takes just under 5 gallons of distilled water. Pour entire contents of Algae Preventer Solution when you fill the column. DO NOT OVERFILL. When pouring water into the Column plug the unit in so the air pump is running. This will let you know the maximum water level when the unit is running. To add water, either remove the entire lid or just the small plug in the middle of the lid and use the funnel to control spillage. Before putting the covers on the platform you can adjust the air-flow to the tube that controls the speed of the ping balls by turning the white pinch valve on the air hose leading to the tube.

### **B. LED SETTINGS**

The Unit comes pre-set from the factory with the M3 setting. A Remote Control is provided if you want to change the setting. Changes should be made by the Therapist ONLY.

**-REMOTE OPERATION-Explanation of Controls**

MODE-Press to change to next Mode

PAUSE – Press to make LED Color stay at present; press again to move on.

SPEED UP- Press to change speed of color change faster.

SPEED DOWN – Press to change speed of color change slower.

#### MODES

M1-Seven Color Flash

M2-Leaning Color Fade

M3- Full Color Fade

M4-Loop

M5-11 – Seven Color Fixation

An instruction from the LED manufacturer is also included with the Remote.

#### **C. CLEANING / INSPECTION / MAINTENANCE**

Recommended cleaning solution is a 50/50 mixture of Hydrogen Peroxide and water and/or a small amount of mild detergent. Use a soft cotton cloth in conjunction with any cleaner.


**DO NOT USE ANY CLEANING PRODUCTS CONTAINING ISOPROPYL OR ETHYL ALCOHOL. DO NOT USE ANY AEROSOL SPRAYS AS THEY ALL CONTAIN ALCOHOL. DO NOT USE ABRASIVE CLEANERS, AS THEY WILL SCRATCH. DO NOT USE PAPER TOWELS AS MAY SCRATCH THE BUBBLE TUBE.**

#### **D. MAINTENANCE**

BUBBLE TUBE – Only Distilled Water should be used in the tube for operation. The water should be replaced every three (3) months with fresh Distilled Water. To drain, lift wood cover on the base of the bubble tube and attach the supplied hose to the drain at the base of the tube. Water can be drained into a floor drain or small bucket. Remove drain hose attachment before filling with fresh water. The Bubble Tube holds slightly less than five (5) gallons of water. Fill the Bubble Tube with the pump running to the label near the top of the tube marked “Do Not Use Alcohol to Clean” to be sure not to overfill. When adding new water 2 ounces of diluted, or a few drops of concentrated anti-algae preventer should be added to the water.

**Safety Precautions** - The safety of your clients is dependent on the appropriate choice of activity to match, yet challenge their physical abilities. Use appropriate spotting / safety techniques. In addition, the layout of your activity area, proper installation and maintenance of your equipment is critical. Southpaw equipment is not intended for recreational or outdoor use. Under no condition should this equipment be used without proper supervision.

**This sheet is for example only.** It is not meant to, in any way, replace local, county, state, or Federal standards. Be aware - it is your responsibility to find all pertinent safety information that pertains to your facility.



**Southpaw  
Enterprises Inc.®**

If you have any questions or comments, please call or write  
Southpaw Enterprises, Inc.

P.O. Box 1047, Dayton, Ohio 45401 -1047

Toll Free - (800) 228-1698

Come see us on the World Wide Web at

<http://southpawenterprises.com>