



Instruction Sheet

Activity Tower Hammock 152021

Store these instructions with the enclosed maintenance checklist in a safe place. You may also access them on our website.



Take time to familiarize yourself with the use and maintenance of this equipment before using. Please file this Instruction Sheet in an accessible location: the Instruction Sheet must be read and familiar to anyone who is using Southpaw Enterprises Equipment.

IMPORTANT: Please check equipment immediately for any damage that may have resulted during shipping. If any damage has occurred, please contact Southpaw Enterprises, Inc. immediately.

MATERIALS LIST

- 2 - Activity Tower Hammock Panels
- 4 - Hanging Straps
- 1 - Instruction Sheet
- 1 - Maintenance Checklist

WORKING LOAD: 65 lbs. per layer / 250 lbs. total

Hanging the hammock

The Southpaw's hammock can be suspended in two ways.

- 1) It can be suspended by four points by putting the corner snaps together.
- 2) It can have each corner connected to its own eyebolt.

Do not use the hammock while in possession of any object that could damage the fabric, such as a pencil or a comb.

The hammock is suspended between the Activity Tower and the Activity Tower ladder by running hanging straps through both panels of the hammock at each corner, attaching two corners to the top rung on both the Activity Tower and Monkey Bar ladder.

Your client may need assistance to enter and exit the swing.

MAINTENANCE CHECKLIST:

All of the following wear points should be checked on a monthly basis and recorded on the checklist enclosed.

- Check for wear or loose stitching on the material at the corners of the hammock where the hanging straps are attached. If wear is found, discontinue use until repaired.
- Check wood rungs where swing attaches for splintered wood, discontinue use until repaired.
- Check hanging straps for fraying or loose stitching, discontinue use until repaired.
- Check the corners of the hammock swing. These areas are critical. If the stitching is coming loose, or the Lycra is torn or pulling out of the corner, discontinue use until repaired.
- Check seams for loose or missing stitches. If loose or missing stitches are found, discontinue use until repaired.

MATTING PRECAUTIONS:

- Always use appropriate matting.
- Crash mats and wall mats must be used with all hanging equipment.

STORAGE PROCEDURES:

- Store out of direct sunlight.
- Store where not accessible by clients without proper supervision.

CLEANING INSTRUCTIONS:

- Check with your infectious disease department before using these procedures.
- Check for client allergies first.
- Machine wash warm water, mild detergent. Tumble dry, low heat.

CAUTION

Floor mats of proper thickness should be positioned properly under and around all suspended equipment.

Safety Precautions - The safety of your clients is dependent on the appropriate choice of activity to match, yet challenge their physical abilities. Use appropriate spotting / safety techniques. In addition, the layout of your activity area, proper installation and maintenance of your equipment is critical. Southpaw equipment is not intended for recreational or outdoor use. Under no condition should this equipment be used without proper supervision.

This sheet is for example only. It is not meant to, in any way, replace local, county, state, or Federal standards. Be aware - it is your responsibility to find all pertinent safety information that pertains to your facility.

If you have any questions or comments, please call or write
Southpaw Enterprises, Inc.

P.O. Box 1047, Dayton, Ohio 45401 -1047

Toll Free - (800) 228-1698

Please visit us @ www.southpaw.com

© 2019 Southpaw Enterprises, Inc.