



southpaw enterprises, inc.[®]

Instruction Sheet

Southpaw Scooter Ramp 150060

Store these instructions along with the enclosed maintenance checklist in a safe place. You may also access them on our website.



Take time to familiarize yourself with the use and maintenance of this equipment before using. Please file this Instruction Sheet in an accessible location: the Instruction Sheet must be read and familiar to anyone who is using Southpaw Enterprises Equipment.

IMPORTANT: Please check equipment immediately for any damage that may have resulted during shipping. If any damage has occurred, please contact Southpaw Enterprises, Inc. immediately.

MATERIALS LIST:

- 1 - Base (four pieces)
- 1 - Ramp
- 10 - Screws
- 1 - Allen Wrench
- 1 - Instruction Sheet
- 1 - Maintenance Checklist



ASSEMBLY:

- Unpack all pieces of the Scooter Ramp
- Select the four pieces of the base. Notice that on one end of each side that there is a notch cut out where the ramp attaches. This is the front of the side piece. On the top of the base there is a strip of wood that serves as a stop to keep the scooter board from running off the back.
- Protect a flat, stable work surface with cardboard from the package. Lay both sides pieces on the cardboard with the front edges together and the bottom edges towards you. Start 5 screws into each of the sides using the allen wrench provided. Allow the tips of the screws to protrude slightly. This will help to align the sides with the top and cross brace. Assemble one side to the top with the stop facing up and the end of the top with the stop even with the rear edge of the side. Attach the brace to the first side. Lay the assembly on the side, so the top and brace are pointing upwards. Line up the second side with the top and cross brace and tighten the screws.
- Verify all of the screws on both sides of the base are tight.
- Attach the ramp to the base by aligning the notches in the end of the ramp with the notches on the base. Press down on the end of the ramp to make sure it is seated into the base.

WORKING LOAD: 250 lbs.

MAINTENANCE CHECKLIST:

All of the following wear points should be checked on a monthly basis and recorded on the checklist enclosed.

- Check wood for cracks or splinters. If cracked discontinue use. For splinters, sand smooth and refinish with clear lacquer.
- Check for loose screws. If loose screws are found, tighten before using the ramp.

STORAGE PROCEDURES:

- Store where not accessible by clients without proper supervision.

CLEANING INSTRUCTIONS:

- Check for client allergies first.
- Check with your infectious disease department before using these procedures.

- Clean with a damp cloth using soap and water or disinfectant.
- Dry before using.

MATTING PRECAUTIONS:

- Always use appropriate matting.

Safety Precautions - The safety of your clients is dependent on the appropriate choice of activity to match, yet challenge their physical abilities. Use appropriate spotting / safety techniques. In addition, the layout of your activity area, proper installation and maintenance of your equipment is critical. Southpaw equipment is not intended for recreational or outdoor use. Under no condition should this equipment be used without proper supervision.

This sheet is for example only. It is not meant to, in any way, replace local, county, state, or Federal standards. Be aware - it is your responsibility to find all pertinent safety information that pertains to your facility.



If you have any questions or comments, please call or write
Southpaw Enterprises, Inc.
P.O. Box 1047, Dayton, Ohio 45401 -1047
Toll Free - (800) 228-1698
Come see us on the World Wide Web at <http://southpawenterprises.com>